## DC12V 10A RELAY 4 CHANNEL WIRELESS RF REMOTE CONTROL SWITCH TRANSMITTER RECEIVER



## **Description:**

Battery Type: 1pc L1028 battery (not included)

Remote Distance: 20-30m (Theoretical value)

Input Voltage: DC 12V

Operating Frequency: 433/315MHZ (We send 433MHZ in normal, if you need 315MHZ, please leave us a

message/email.)

Channel Numbers: 4 CH

Operation Way: Inching, Self-locking

Coding Way: Intelligent Learning

Operating Temperature: -40°C ~ +80°C

Output Current: ≤ 10A

Receiver Sensitivity: ≥-105dBm

Factory Default: Self-locking

Code:Learning Code (jog/Non-Latched .inter-lock/Latched .self-lock /Self Latched)

Board Dimension: 72.5x52.5x23mm

Case Dimension: 74x53x30mm

## Learning and remove method:

- 1. Press the first learning code .the indicator flash ,loosen your finger ,press first button of the remote control ,the indicator flash 2 times and off .press the second learning code .the indicator flash ,loosen your finger ,press second button of the remote control,the indicator flash 2 times and offit mean you learn it successfully .
- 2. Remove/clean: press the learning button about 8 seconds, the indicator turn on to off, it means the information that you keep have been removed successfully.

## Package Included:

1X Transmitter (Battery is not included)

1X Receiver